

other platings on request

When using this female connector as a bottom entry connector, we

recommend that the Pin Header pins protrude by around 2.00mm

above the surface of the female connector after assembly. This

will avoid any risk of separation of the Pin Header from the Female

Header during shock and vibration.

with "locating pegs" (available only from 006 to 080 contacts)

Tube packing; without "PickUp Cap" С =

- Tube packing; with "PickUp Cap" D =
- Ε Reel packing; with "PickUp Cap" =

В Reel packing; with "PickUp Cap" =